

Crowns & Denture Combination Cases from Prep to Completions

Evolution Dental Solutions – Linda Kilgus RDT / Master Ceramist
www.EvolutionDentalSolutions.com info@EvolutionDentalSolutions.com

Prep the teeth .

Impression Taking

Take full arch impressions of mandibular and maxillary arches so crowns, and custom trays along with bite block can be made. This requires 7 days min.

Try in crowns

Take pickup impression

Take pickup impressions of crowns directly involved with partial such as ones with an attachment. using the custom trays and alginate. This will displace less tissue than silicone. Temporarily cement the crowns that are involved with the partial before taking impressions , then remove them and place them into the impression. this will ensure that they do not move in the mouth while taking impressions. Any other crowns without direct involvement with partial denture may be permanently cemented in place before impressions.

Use bite blocks.

Then the partial framework is made and teeth are set up in wax to try in.

Try in crowns and partial.

If all fits well send back to process partial to finish. 2 – 3 days.

Insert all together.